



How to reset the Open Firmware settings on pre-Intel Macs:

1. Power on while holding **cmd-alt-O-F**
2. At the Open Firmware prompt, type: **reset-nvram**
3. Press Return.
4. At the Open Firmware prompt, type: **reset-all**
5. Press Return. The Mac should now automatically restart.

Example:

```
0 > reset-nvram  
Press Return  
0 > reset-all  
Press Return
```

Note: The open firmware system was replaced on Intel Macs with the Systems Management Controller.